

10 EASY STEPS – USING THE BALL MACHINE

- 1) Place machine on cart and bring onto the far side of the court (position it at center baseline).
- 2) Run extension cord back to the fence and then to court electrical outlet.
- 3) Lift the plastic ball holder flaps, load tennis balls, power on the machine, and wait a bit.
- 4) When it starts beeping, press the PLAY button on the machine.
- 5) On your phone, connect to the machine's Wi-Fi (will be called "USR-xxx")
- 6) Open the Drillmaker Spinshot-2 App on your phone.
- 7) If buttons are green, you're ready, otherwise you will be asked to connect.
- 8) Select the drill you want, press START and hit some balls. Note that you can change drills on the fly.
- 9) When finished, make sure all the balls are out of the machine, close the flaps and, power off the machine. If you are done and there are balls still in the hopper, first power off/unplug the machine & remove the balls by hand.
- 10) Return the ball machine to the shed along with the cart, extension cord, and ball hopper w/ balls. Place cover on the machine and lock the shed.

Important Warnings:

- Do not reach or look into the ball exit hole without turning the main power off, and only after both wheels come to a COMPLETE stop.
- Do not stand closer than 30 feet in front of the ball machine when the power is on.
- Do not place balls or foreign objects into the ball hopper while the feeder tray is moving. It could cause a jam and damage the feeder motor. Overloading of balls into the ball hopper may result in a jam of the feeder. No more than 120 balls should be put inside the ball hopper.
- Do not use your machine while it is raining. Do not use wet tennis balls.